

INSTRUCTIONS



UNITED STATES

1-800-432-5437

Fisher-Price, Inc. 636 Girard Avenue, East Aurora, NY 14052
Hearing-impaired consumers: 1-800-382-7470

CANADA

1-800-432-5437

Mattel Canada Inc. 6155 Freemont Blvd.
Mississauga, Ontario L5R 3W2



SMART CARDS

© & ™ Mattel and Smart Toy LLC. All Rights Reserved.
® and ™ designate U.S. trademarks of Mattel, except as noted.

PRINTED IN CHINA

DNV53-0970
1100922421-DOM

Remark:

Revision	Date	ID#	Changes
Primary - pr	07/13/2015	DNV53-0970-1100922421-DOM	NA



WHAT DO YOU WANT TO DO NEXT?

Before using your new Smart Cards for the first time:

- Download and connect Smart Toy to the parent app (if you haven't already).
Go to: <http://www.smarttoy.com/app>
- Make sure Smart Toy is being used where you initially connected it to Wi-Fi.



Keep these instructions for future reference, as they contain important information.

